SONY
make.believe

AKA-RD1

Action Cam Replacement Door Pack

Replacement Door Pack

A three pack of replacement doors for Sony® Action Cam. Replace the doors on your Action Cam waterproof case (included with Action Cam purchase) to take advantage of different shooting scenarios and conditions. Your pack includes a standard replacement door should your original door[1] get[1] scratched, a door with a flat lens (ideal for shooting underwater)[1] and a door with a slight opening near the embedded microphone (to realize improved audio).[2]

Specifications

1. When used with Waterproof case (SPK-AS1) Action Cam is waterproof down to 197ft (60m)
2. When used with Waterproof case (SPK-AS1) Action Cam is waterproof down to 33ft (10m)

© 2012 Sony Electronics Inc. All rights reserved. Reproduction in whole or in part without written permission is prohibited. Sony and the Sony make.believe logo are trademarks